

## **UltraClip Installation**

1.





## 2. Tension Adjustment



- 1. Lever should be at a max angle of 45° to the top of the board when you start to feel resistance.
- resistance.
  2. You should be able to close the lever by pushing with your thumb only. Any more force required can damage the UltraClip or your board.
- 3. With the hook in the desired position tighten with 1/8" allen key and 3/8" wrench. Turn wrench until nut touches hook and turn wrench 1/4 turn to 3/8 turn more. Do not over tighten as the hook is designed to slide in case of an overload.